



ULTRATECH
INTERNATIONAL, INC.

Ultra-Hose Connector[®] Instructions



FOR QUICK AND EASY HOSE CONNECTIONS WITH ULTRA-DEWATERING BAGS AND ULTRA-PIPE SOCKS (NOT INCLUDED)

1. Remove the Ultra-Hose Connector from the shipping box. The unit is ready for use.
2. Remove the stainless steel clamp by pushing up on the screw with your thumb.
3. Screw the threaded end of the Ultra-Hose Connector to the pump hose.
4. Place the opening of the Ultra-Dewatering Bag or Ultra-Pipe Sock on the Ultra-Hose Connector, gathering it together in the constricted area between the two ends of the connector. Replace the steel clamp by inserting the notched end into the fitting. Tighten the clamp with a flat-head screwdriver to secure the Ultra-Dewatering Bag or Ultra-Pipe Sock.
5. Begin pumping into the Ultra-Dewatering Bag until pumping is complete or the bag is full, or through the Ultra-Pipe Sock as needed.
6. Hold the opening of the Ultra-Dewatering Bag or Ultra-Pipe Sock in a slightly elevated position, and push up on the clamp screw to release the bag.
7. Roll the end of the opening two to three turns and use the attached ties on the UltraDewatering Bag or Ultra-Pipe Sock to secure the opening.
8. If additional Ultra-Dewatering Bags or Ultra-Pipe Socks are need at this site, attach per step 4 above.
9. When the dewatering is complete, unscrew the Ultra-Hose Connector from the pump hose, re-attach the stainless steel clamp and wipe down the unit with a clean cloth.

