



ULTRATECH
INTERNATIONAL, INC.

Ultra-IBC Berm® Assembly Instructions

Sold by:
ONE
CLARION

Site Preparation: Select a level area and be sure that the ground is swept clean of debris and sharp objects. Place the folded berm at the setup location. Do not drag the folded berm. Pallet should not be placed inside of the berm until after the berm is completely assembled.

1. Unpack and unfold the berm.



2. Unpack L-brackets provided.



3. Slide L-brackets into the Berm pockets to support the sidewalls. Do this for all but the one wall that will be used to load the spill pallet and IBC.
(NOTE: the longer (17") side of the bracket should be inserted into the sleeve. The shorter (11") side will go underneath the berm.)

4. Load the spill pallet by hand, with forklift or other equipment.



5. Install remaining L-brackets.
6. Your Ultra-IBC Berm is now ready for use.



- + To lower a sidewall simply remove enough L-brackets to allow ample room for forklift, pallet jack, vehicle to enter or exit.
- + Insure L-brackets are re-installed.
- + Remove chemical and/or oil spills immediately in accordance with local regulations and statues.
- + Remove capture rain/stormwater in order to provide full capacity in the case of a spill.