



ULTRATECH
INTERNATIONAL, INC

Sold by:
ONE
CLARION

Ultra-Post Protector®

Installation Instructions

1. **Slide the Ultra-Post Protector over existing post to check fit.** (The Post Protector inside diameter is always bigger than the listed size. For example, a 6-inch Post Protector has an actual inside diameter of seven (7) inches.
2. **Apply the neoprene adhesive tape** (included) approximately three (3) inches down from the top of the post and three (3) inches up from the bottom of the post. If a tighter fit is needed, slightly overlap the tape directly underneath the existing tape. Use one continuous piece of tape. (Tape length will vary according to post diameter).
3. With a twisting motion, slowly **slide the Ultra-Post Protector over the existing post.** If this is done correctly, you should hear air seeping out between the post and the Post Protector.

If the above directions are followed correctly, the Ultra-Post Protector should fit tightly with no gap between the pipe and Protector. The Ultra-Post Protector will not be easily removed.

